



# VSW LAK

## Montagehinweis / Installation instructions / Instructions d'installation / Istruzioni di montaggio



Hydraulischer Anschluss Hydraulic connection Raccordement hydraulique Collegamento idraulico	Elektrischer Anschluss / Electrical connection / connexion électrique / connessione elettrica		
	<b>Regler WPM (YM 18)</b> Controller Régulateur Regolatore	<b>Stellmotor</b> Actuator Servomoteur Servomotore	
	<b>N:</b> X2/N  N1-J22/Out6  <b>L:</b> X2/L		

